

MSI-8000HD

RF Indicator

Technical Manual



© Rice Lake Weighing Systems. All rights reserved.

Rice Lake Weighing Systems® is a registered trademark of
Rice Lake Weighing Systems.

All other brand or product names within this publication are trademarks or
registered trademarks of their respective companies.

All information contained within this publication is, to the best of our knowledge, complete and
accurate at the time of publication. Rice Lake Weighing Systems reserves the right to make
changes to the technology, features, specifications and design of the equipment without notice.

The most current version of this publication, software, firmware and all other product
updates can be found on our website:

www.ricelake.com

Revision History

This section tracks and describes the current and previous manual revisions for awareness of major updates and when the updates took place.

Revision	Date	Description
A	March 15, 2017	Initial manual release with the launch of the product;
C	October 13, 2022	Revision history established with Rev C
D	September 2, 2026	Updated communication terminology

Table i. Revision Letter History



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.

Contents

1.0	Introduction	7
1.1	Safety	7
1.2	Disposal	8
1.3	FCC Compliance	8
1.4	Front Panel Description	9
2.0	Installation	10
2.1	Unpacking	10
2.2	Getting Started	10
2.3	Opening the Enclosure	10
2.4	Wiring	11
2.5	Mounting the MSI-8000HD	12
2.5.1	Mounting with Tilt Stand	12
2.5.2	Direct Mounting	12
3.0	Operation	13
3.1	Power	13
3.2	Zero	13
3.3	Tare	13
3.3.1	View Tare	13
3.3.2	Clear Tare	13
4.0	Setup	14
4.1	Setup Navigation	14
4.2	Setup Menu	14
4.3	Function Keys	16
4.3.1	Test	16
4.3.2	Total	16
4.3.3	View Total	17
4.3.4	Net/Gross	17
4.3.5	Peak Hold	17
4.3.6	2Unit/5Unit	17
4.3.7	Hi-Res	17
4.3.8	Print	18
4.3.9	Scan	18
4.3.10	Add Load	18
4.4	Auto-Off	18
4.5	Setpoints	19
4.6	Output	20
4.7	Battery Life – Optional	20
4.8	Total Mode	21
4.9	Filter Setup	22
4.10	Unit	22
5.0	Calibration	23
5.1	Calibration Switch	23
5.2	Initial Calibration	24
5.2.1	Routine Calibration	25



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars

5.2.2	C-Cal Calibration	26
5.3	Setup	27
5.3.1	Standard Settings	27
5.4	Reset the Load Cell Calibration	28
5.5	Auto Zero Maintenance (AZM)	28
5.6	Zero Power Up (0.P-UP)	29
6.0	Communications	30
6.1	Communications Setup	30
6.2	Communications Menu	30
6.3	Printer Setup	31
6.3.1	Control Modes	31
6.3.2	Standard Print Strings	32
6.3.3	Printer Output Setup	33
6.4	RF Network Setup	34
6.5	AD Inputs	35
6.5.1	Set the Total Number of Load Cells	35
6.5.2	Scan Weight Inputs	36
6.5.3	Load Totaling Settings	36
6.6	Zero and Tare in Multiple Load Cell Systems	36
6.7	Communications Port Hardware	37
6.8	Relays	38
6.8.1	Relay Options	39
6.8.2	Extended Relay Kit – Optional	40
6.9	Radio Compliance	40
6.9.1	802.15.4 (XBee 3 and XBee 3-PRO)	40
6.9.2	802.15.4 (XBee 2SC)	41
6.9.3	Wi-Fi	41
6.9.4	WPAN	41
6.9.5	FHSS (Frequency Hopper Spread Spectrum)	41
6.10	Antenna Options	42
6.10.1	Available Antennas	43
6.11	Direct Download into Excel Spreadsheet	44
7.0	Optional Rugged Remote	45
7.1	Operation	45
7.1.1	Power	46
7.1.2	Zero	46
7.1.3	Programmable Function Keys	46
7.2	Conflict and Jamming Considerations	46
7.3	FCC Compliance	46
8.0	Troubleshooting and Maintenance	47
8.1	Troubleshooting	47
8.2	Error Codes	48
8.3	Service Counters	48
8.3.1	Access the Service Counters	48
8.4	Mechanical Dimensions	49
8.5	Firmware Update	50
8.6	Factory Reset	51
9.0	Specifications	52



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.



*Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit **www.ricelake.com/webinars***

1.0 Introduction

The MSI-8000HD RF Indicator is a combination of the sound and proven mechanical design of the industry standard, with today's most advanced electronics. It provides a superb feature set unmatched by any scale in its class or price range. The MSI-8000HD is versatile, reliable, accurate and easy to operate. RF remote control and remote display options are available to further enhance the safety and usability. It has RF effective range of over 100 ft (line of sight) and operates on a license-free 2.4 GHz frequency.

It is fully sealed for outdoor use in most ambient conditions. Installed optional relays optimize work-flow and process control. This manual is intended for use by qualified technicians responsible for setting up and operating the MSI-8000HD.



Manuals are available from Rice Lake Weighing Systems at www.ricelake.com/manuals

Warranty information is available at www.ricelake.com/warranties

1.1 Safety

Safety Definitions:



DANGER: Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. Includes hazards that are exposed when guards are removed.



WARNING: Indicates a potentially hazardous situation that, if not avoided, could result in serious injury or death. Includes hazards that are exposed when guards are removed.



CAUTION: Indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury.



IMPORTANT: Indicates information about procedures that, if not observed, could result in damage to equipment or corruption to and loss of data.

General Safety



Do not operate or work on this equipment unless this manual has been read and all instructions are understood. Failure to follow the instructions or heed the warnings could result in injury or death. Contact any Rice Lake Weighing Systems dealer for replacement manuals.



WARNING

Failure to heed could result in serious injury or death.

Do not stand near the load being lifted as it is a potential falling hazard. Keep a safe distance.

Do not use for purposes other than weight taking or dynamic load monitoring.

Do not use any load bearing component that is worn beyond 5% of the original dimension.

Do not use any associated lifting product if any of the load bearing components are cracked, deformed or show signs of fatigue.

Do not exceed the rated load limit of the associated Scale/Dynamometer unit, rigging elements or the lifting structure.

Do not allow multi-point contact with the hook, shackle or lifting eye of the associated Scale/Dynamometer unit.

Do not allow high torque on the Scale/Dynamometer unless it is specifically designed for high torque.

Do not make alterations or modifications to the unit or associated load bearing devices.

Do not remove or obscure warning labels.

For guidelines on the safe rigging and loading of overhead scales and dynamometers, read the MSI Crane Scale Safety and Periodic Maintenance Manual, PN 153105.

Keep hands, feet and loose clothing away from moving parts.

There are no user serviceable parts within the MSI-8000HD. Any repairs are to be performed by qualified service personnel only.

Close proximity to audible alarm for sustained periods of time could be hazardous. Hearing protection may be required.

Do not use solvents or aggressive substances to clean the indicator.

Do not submerge.

1.2 Disposal



Product Disposal

The product must be brought to appropriate separate waste collection centers at the end of its life cycle.

Proper separate collection to recycle the product helps prevent possible negative effects on the environment and to health, and promotes the recycling of the materials. Users who dispose of the product illegally shall face administrative sanctions as provided by law.

Battery Disposal

Dispose of batteries at appropriate waste collection centers at the end of their life cycle in accordance with local laws and regulations. Batteries and rechargeable batteries may contain harmful substances that should not be disposed of in household waste. Batteries may contain harmful substances including but not limited to: cadmium (Cd), lithium (Li), mercury (Hg) or lead (Pb). Users who dispose of batteries illegally shall face administrative sanctions as provided by law.



WARNING: Risk of fire and explosion. Do not burn, crush, disassemble or short-circuit batteries. Do not replace battery with incorrect type.

1.3 FCC Compliance

United States

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Canada

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la Class A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

1.4 Front Panel Description

The MSI-8000HD front panel, keys and annunciators, are described in [Table 1-1 on page 9](#).




Figure 1-1. MSI-8000HD Front Panel

Key/Annunciator Functions

Item No.	Key	Description
1	Function 1	Programmable to user selectable functions (Section 4.3 on page 16); Default is Off ; Functions as the Enter/Select key when in the setup menus
2	Function 2	Programmable to user selectable functions (Section 4.3 on page 16); Default is Off ; Functions as the Scroll key in the setup menus
3	Function 3	Pre-programmed to Print and cannot be changed
4	Center of Zero	Indicates that the scale/Dyna-Link is within 1/4 d of zero
5	Standstill	Indicates that the load has settled within the motion window (usually ± 1 d); When this is turned off, the scale/Dyna-Link will not zero, tare or totalize
6	LED Functions	Indicates the current displayed function <i>Example: If F1 blinks, the peak hold reading is captured. If F2 blinks, the Display and Function Test reading is captured.</i>
7	Total	Indicates the RF linked device is displaying the total accumulated weight; Displays only momentarily
	Peak	Indicates the RF linked device is in the peak hold mode
	Net	Indicates the RF linked device is in Net load mode; A tare weight is subtracted from the gross load
	Metric Ton	In conjunction with the Ton annunciator, indicates the RF linked device is displaying metric tons
	Ton	Illuminated, indicates the RF Linked Device is displaying in U.S. Short Tons (1 ton = 2000 lb); When illuminated with M the RF Linked Device is displaying in metric tons (1 metric ton = 1000 kg)
	Kilonewtons	Indicates load display is in kilonewtons
	Kilograms	Indicates load display is in kilograms
	Pound	Indicates load display is in pounds
8	Setpoints	User programmable setpoints for overload warnings; Setpoints 1 and 2 are red high brightness LEDs
9	Multiple Sensors	Number lit indicates the sensor being displayed; If more than one number is lit, sensors are being summed <i>Example: If both numbers 1 and 2 are lit, then the weight displayed equals the sum of sensor 1 and sensor 2.</i>
10	Display Digits	Include six 1.22" (31 mm) sunlight visible LCD's
11	Power	Powers the unit on and off; In setup mode, it returns the display to the weigh mode without storing changes
12	Zero	Zeros the residual load on a scale/Dyna-Link 2; In setup mode, it stores changes and returns to the prior level
13	Tare	Removes current load value and puts the system into Net weight mode
14	Low Battery	Indicates about 10% of battery life remains; Symbol flashes when automatic shutdown is eminent

Table 1-1. Keypad/Annunciator Functions

2.0 Installation

This section provides an overview of MSI-8000HD RF Indicator installation instructions.

2.1 Unpacking

When unpacking the MSI-8000HD, ensure that all parts are accounted for and check for any visible damage. If any parts were damaged in shipment, notify Rice Lake Weighing Systems and the shipper immediately. If the MSI-8000HD must be returned, it must be properly packed with sufficient packing materials. If possible, retain the original carton when shipping the unit back.

2.2 Getting Started

The MSI-8000HD is often shipped pre-configured with a compatible sensor unit such as an Dyna-Link 2 or one of the MSI crane scales. If the MSI-8000HD is purchased separately, or is to be used with a different system, the RF transceivers will have to be paired. Follow the RF Setup Procedure in [Section 6.4 on page 34](#).

Once the RF setup is complete for the MSI-8000HD, the system will automatically connect with a scale/Dyna-Link. It is recommended to do a site survey to identify operating range and usability of the RF Link. Position the scale/Dyna-Link at an average operational height, and try the link at various positions and distances. The range may vary by the rotation of the scale/Dyna-Link, as well as the site and installation variables.

Battery Charging (Optional)

For units with an optional battery, fully charge the battery by plugging the charger into the charge port. Depending on the discharge level of the battery this can take up to six hours.



Figure 2-1. Battery Charger

2.3 Opening the Enclosure



The indicator enclosure must be opened to connect the scale load cell cable and other interface connections.



WARNING: Before opening the unit, ensure the power cord is disconnected from the power outlet.

1. Disconnect the power to the indicator.
2. Place the indicator face down on an anti-static work mat.
3. Remove the screws that secure the backplate to the enclosure.
4. Lift the backplate away to access the boards and set it aside.

2.4 Wiring



2.5 Mounting the MSI-8000HD

The MSI-8000HD can be placed on a table, counter or table using the tilt stand. The tilt stand is equipped with four rubber bumper to keep it from sliding while using the MSI-8000HD.

2.5.1 Mounting with Tilt Stand

A tilt stand is shipped with the MSI-8000HD for mounting. It can be mounted on a desk, counter or table. It can also be mounted to a wall or panel and the MSI-8000HD can be rotated for easy viewing.




Figure 2-4. Tilt Stand – Bottom Dimensions

To secure to one of the options above:

1. Using the tilt stand, mark holes as needed.
2. Drill the holes for the hardware being used.
3. Secure the tilt stand to the surface. If mounting to a wall or panel, ensure it is mounted horizontally.
4. Install the MSI-8000HD into the tilt stand at an angle that will allow easy viewing.

2.5.2 Direct Mounting

The MSI-8000HD can be mounted directly to a wall or panel using the four holes in the corners of the unit.

1. Hold the remote display against the wall or panel where it is to be mounted.
2. Mark the hole location. This can also be done by measuring according to the dimensions in [Figure 2-5](#).
3. Drill the holes as needed.
4. Align the unit with the holes and secure with the appropriate hardware.




Figure 2-5. Mounting Hole Dimensions

3.0 Operation

This section provides an overview of MSI-8000HD RF Indicator operation instructions.



NOTE: Ensure the recommended battery or power supply is secured prior to device operation (Section 2.0 on page 10).

3.1 Power

Power the indicator On/Off by pressing



3.2 Zero

Press  to take out small deviations in zero when the scale is unloaded. For zeroing (taring) package or pallet weights, see Section 3.3. The zero key can be used in **GROSS** or **NET** mode.



NOTE: The backup memory in the unit stores the zero reading and retains it even if the power fails.

Zeroing while in **NET** mode will zero the **GROSS** weight causing the display to show a negative tare value.

The scale must be stable within the stable window.

The unit will only zero if  is on and there has been no activity for two seconds.

The scale will accept a zero setting over the full range of the scale (NTEP and other Legal for Trade models may have a limited zero range).

Zero settings above 4% of full scale will subtract from the overall capacity of the unit.

Example: If 100 lb on a 1,000 lb scale is zeroed, the overall capacity of the scale will reduce to 900 lb, plus the allowed over-range amount.

3.3 Tare

Tare is used to zero out a known weight, such as a packing container or pallet, and display a **NET** weight. The **TARE** function is defined as a **Tare-In** or **Tare-Out** operation. To tare the scale:

1. Hang the empty container from the scale.
2. Press  to enter a tare value. The MSI-3460C stores the current weight as a tare value and subtracts the value of the container from the **GROSS** weight.  displays and the weight mode changes to **NET**.
3. Add the product to the packing container. The **NET** weight is displayed.

3.3.1 View Tare

To view the **GROSS** weight without clearing the tare value:

1. Program  to the **NET/GROSS** function (Section 4.3 on page 16).
2. Press  to toggle between net and **GROSS** values. This will only work if a tare value has been established.



NOTE: The backup memory in the MSI-8000HD stores the Tare reading and can restore it even if power fails.

Only positive **GROSS** weight readings can be tared. The **STABLE** annunciator must be on, indicating weight reading is stable. Setting or changing the tare has no effect on the **GROSS** zero setting. Taring will reduce the apparent over range of the scale. The RF Remote Control has **NET/GROSS** permanently available.

*Example: Taring a 100 lb container on a 1,000 lb scale, the scale will overload at a **NET** weight of 900 lb (1,000-100) plus any additional allowed overload (usually 4% or 9d).*

3.3.2 Clear Tare

To clear a saved tare value, press



. The **GROSS** weight displays.

4.0 Setup

This section provides an overview of MSI-8000HD RF Indicator setup instructions.

4.1 Setup Navigation

To navigate the menus during setup, follow the information below:

- Press  to enter or select a parameter
- Press  to scroll through the parameters
- To enter a decimal point, press  while the digit is blinking
- Press  to save and go back one level or to weigh mode; *StorE* displays briefly
- If a wrong value is entered, press  to step back one digit and press  to change the digit
- Press  to exit without saving changes

4.2 Setup Menu

To enter the setup menu, press the  and  keys at the same time.



NOTE: Not all parameters are available when the regulatory setting is HB-44 or R76 ([Section 5.3.1 on page 27](#)).

Parameters	Choices	Description
<i>Func 1</i>	Function key 1 – Configurable to listed parameters (Section 4.3 on page 16); Default OFF	
<i>Func 2</i>	Function key 2 – Configurable to listed parameters (Section 4.3 on page 16); Default OFF	
	<i>OFF</i>	No function is assigned; The F-Key is disabled
	<i>tESt</i>	Test – Runs an LCD test (Section 4.3.1 on page 16)
	<i>tOtAL</i>	Total – Accumulates multiple weighments (Section 4.3.2 on page 16)
	<i>U- tEtL</i>	View total – Activates the total weight display followed by the number of samples (Section 4.3.3 on page 17)
	<i>nEtGr</i>	Net/Gross – Toggles between Net and Gross modes (Section 4.3.4 on page 17)
	<i>P-hLd</i>	Peak Hold – Automatically updates the display when a higher peak weight reading is established (Section 4.3.5 on page 17)
	<i>2Un iE</i>	2 Units – Switches the force units between lb and kg (Section 4.3.6 on page 17)
	<i>5Un iE</i>	5 Units – Switches the force units between all available units: lb, kg, tons (U.S. short), metric tons, and kilonewtons (Section 4.3.6 on page 17)
	<i>h iRE5</i>	Hi Res – The unit is more sensitive to motion and movement resulting in a less stable display (Section 4.3.7 on page 17)
	<i>Pr iNt</i>	Print – Outputs a configured text string to the RS-232 port on the base of the Dyna-Link (Section 4.3.8 on page 18)
	<i>tARrE</i>	Tare – Can be programmed to a F-key if desired; The MSI-8000HD has a dedicated tare key so it is not necessary
	<i>ScAn</i>	Scan – Scan each channel to switch scales to view weights (Section 4.3.9 on page 18)
	<i>Add .Ld</i>	Add Loads – Switching display summing methods of local physical load pins (all, pairs or both) (Section 4.3.10 on page 18)

Table 4-1. Setup Menu Parameter Descriptions

Parameters	Choices	Description
Auto Off	OFF 15 30 45 60	Auto Off – Prolongs the battery life of the scale by turning power off after the set time (in minutes) that the scale is not in use (Section 4.4 on page 18)
Setpoints	--	Setpoints can be enabled/disabled only when using the remote display (Section 4.5 on page 19)
Setpoint 1-8	GREATER	Greater Than – Setpoint triggers when the tension exceeds the value
	LESS	Less Than – Setpoint triggers when the tension is less than the value
	OFF	Off - Setpoint parameter is disabled
Output		Relay Output – Dependant on the application being used (Section 4.6 on page 20)
	LATCH	Latch – If power is lost, the relay retains it's settings
	COIL	Coil – Needs power to remain position
Battery Life	Standard Long	Battery Life (Optional Feature) – Sets the option for standard or extended battery life (Section 4.7 on page 20)
Total	OFF	Total Accumulation - Sets the choice for weight accumulation for a single scale See Section 4.8 on page 21 ; When set to off, it is disabled
	TOTAL ON	Total On - Is a manual choice for accumulation
	Auto Load Auto Load Manual On	Auto Total - Choices for setting automatic accumulations
Weight Filter	OFF L0 h r 1 h r 2	Weight Filter – Allows the scale to adjust to situations where there may be movement (Section 4.9 on page 22)
Units	lb kg Ton Mton kN	Weight Units – Toggle units between pounds and kilograms (Section 4.10 on page 22)

Table 4-1. Setup Menu Parameter Descriptions (Continued)

4.3 Function Keys

There are two programmable function keys on the MSI-8000HD, **F1** and **F2**.

- Function key setup is independent of the connected scale/Dyna-Link function keys
-  and  are standard on the MSI-8000HD and do not need to be programmed
- If a function key does not work, the connected Scale/Dyna-Link may not be set up to support the key
Example: If the Function key is set for TOTAL, then TOTAL mode setup in the Setup Menu must also be set up for the target scale.

To set a function key use the following steps:

1. Press  and  at the same time, *F_{UNC} 1* will display.
2. Press  to scroll to the function key to be programmed.
3. Press . The currently saved parameter will display.
4. Press  to scroll through the choices.
5. Press  to select the desired choice.
6. Press  to save and exit.

4.3.1 Test

The test feature only tests the MSI-8000HD. Set an **F-key** to **TEST**.

To run a test, press **Fx-TEST**, the following items scroll across the display.

- Light all LCD segments and the LEDs
- *S_oF_t* followed by the version number
- *S_tA_nd* followed by the weighing standard
- *bA_tt* followed by the battery level in volts
- *d . t E S t* followed by counting from 00000–99999

The test can be single stepped by:

1. Press **Fx-TEST**, immediately press  to stop the auto scroll.
2. Use  to scroll through the steps and  to view the step value.
3. Press  to abort the test at any time.

Internal tests are also performed, if any test fails, an error code is displayed. See [Section 8.2 on page 48](#) for a description of all error codes.

4.3.2 Total

1. Ensure the total mode has been programmed in the setup menu. If this has not been setup the **F-Key** assigned to **Total** will not work.
2. Program an **F-key** to **Total** ([Section 4.3 on page 16](#)).
3. Press **Fx-Total** to perform the total function that was set in [Section 4.8 on page 21](#).

4.3.3 View Total

Displays the total weight followed by the number of samples.

1. Program an **F-key** to **View Total** (Section 4.3 on page 16).
2. Press **Fx-View Total** to view the total on scale and the number of samples.

4.3.4 Net/Gross

1. Program an **F-key** to **NetGross** (Section 4.3 on page 16).
2. Press **Fx-NetGross** to toggle between gross and net (gross minus tare). **Fx-NetGross** only functions if a tare has been established.
 - The operator can switch back to gross from net without clearing the tare value; Only clearing or setting a new tare will change the tare value held before switching into Gross Mode

4.3.5 Peak Hold

Peak hold uses a high speed mode of the A/D converter allowing it to capture transient loads at a far higher rate than typical Dynameters.

- Peak Hold is cleared and enabled by pressing **Fx-P-HLd**
 - When a new peak is detected, the **Fx** LED will flash three times
 - The accuracy of the system in peak hold is slightly reduced to 0.2% of Capacity + 5 d
 - The filter setting is turned off while in peak hold mode to ensure the fastest acquisition rate
- Example: The Peak Hold function is useful in Dynamic and Fall tests. Common tests include Overall Breaking Strain (OB€), Breaking Force, and Cycled Breaking Strain.*

Capture Peak Force:

1. Program an **F-key** to **P-HLd** (Section 4.3 on page 16).
2. Prepare the stand test and test sample.
3. Press .
4. Press **Fx-P-HLd**, confirm that **Pk** is lit on the display.

 **NOTE: A small jump in the reading occurs depending on the stability of the test device.**

5. Apply the test weight. The **Fx** LED will blink three times when a new peak ID is detected.
6. Remove the weight and the peak value is recorded.
7. To run a new test, press **Fx-P-HLd** to clear the peak value. Repeat Step 3–Step 6.

4.3.6 2Unit/5Unit

Program an **F-key** to either **2-UNIT** or **5-UNIT** (Section 4.3 on page 16).

Press the **2-UNIT F-key** to switch the force units between lb and kg.

Press the **5-UNIT F-key** to scroll through all available units: lb, kg, tons (U.S. short), metric tons, and kilonewtons.

4.3.7 Hi-Res

 **NOTE: Only available with the MSI-7300 Dyna-Link (refer to the Dyna-Link manual PN 152160)**

When set to on, the filter is automatically set to the **Hi-1** setting (if **Hi-2** is already set, then the filter is not changed). This will have a small effect on settling time. When set to off, the filter setting resets to the previous filter setting.

Program an **F-key** to **HiRes** (Section 4.3 on page 16).

Pressing **Fx-HiRes** places the display into a temporary high resolution mode. This mode continues until **Fx-HiRes** is pressed again, or power is cycled. In the Hi-Res mode the appropriate **Fx** LED blinks continuously at a slow rate.

 **NOTE: Hi-Res mode does not increase the accuracy, but allows for smaller weight incrementation to display.**

Use  or  to zero out any initial error.

4.3.8 Print

The **Print** function is set to **F-3 key**, so there is no need to program F1 or F2 to Print. Then pushing F1 or F2 on the scale will cause the Comm Port on the Remote to output the selected data string.

If an **F-Key** is programmed as Print and the Print Setup is configured as continuous, then the **F3-Print** key is used for **Start Print/Stop Print**.

4.3.9 Scan

Scan each channel to switch scales to view weights ([Section 6.5.2 on page 36](#)).

4.3.10 Add Load

Turns on the summing of channels ([Section 6.5.3 on page 36](#)).

4.4 Auto-Off

The **Auto-Off** feature prolongs the battery life by powering off the unit when not in use. When a button is pressed or the detected load is in motion exceeding 10 **d**, the time limit is reset.

When disabled, the unit will only turn off by pressing  , or the battery dies.

To set the **Auto-Off** function:

1. Press and hold  and . **FUNC 1** displays.
2. Press  to scroll to **A-OFF**.
3. Press . The current auto off time displays.
4. Press  to scroll through the available times.
5. Press  when the desired time is displayed. **SLEEP** displays.
6. Press  to exit setup and store the settings.

4.5 Setpoints

The MSI-8000HD supports eight setpoints. Common uses of setpoints are for warnings or process control. It comes standard with two LED outputs for triggered setpoints. The triggering of setpoints 1 and 2 are indicated on the two setpoint relays. All eight setpoints can be used to trigger relays if the MSI-8000HD is ordered with relays.

The MSI-8000HD has an audible output option that is triggered by Setpoint 1. Contact Rice Lake Weighing Systems for other setpoint output options.

Setpoint	Description
Setpoint Mode	
Off	Setpoint is not activated
GREAT	Indicates the setpoint will trigger when the weight exceeds a set value
LESS	Indicates the setpoint will trigger when the weight is less than a set value
Setpoint Weight Type	
NETGr	responds to net or gross weight
GROSS	responds to gross weight regardless of the display
TOTAL	responds to the totaled weight
LCnt	responds to the total count (number of samples)
LFcnt	responds to the number of times the weight has exceeded 25% of capacity

Table 4-2. Available Setpoint Settings

To set the setpoint:

1. Press and hold  and . **FUNC 1** displays.
2. Press  to scroll to the desired setpoint (**SEPt 1 - 8**).
3. Press . The current setpoint mode is displayed.
4. Press  to scroll to the setpoint mode desired.
5. Press . The current setpoint weight type is displayed.
6. Press  to scroll to the desired weight type.
7. Press . The desired weight type continues to display.
8. Press . **Sn 1-4** displays.
9. Press  to toggle between **Sn 1-4** and **Sn 5**.
10. With the desired setting displayed, press . The current weight type value is displayed.
11. Press  to scroll the numbers and  to enter each digit.
12. When the correct value is displayed, press . The next setup menu item is displays.



NOTE: To enter a decimal point, press  while the digit is blinking. To correct a digit, press  to step back.

13. Press  to exit setup and store the settings.

4.6 Output

Relay output allows the selection of Latch or Coil relays.

- Latch relays retain position even if the power fails
- Coil relays reset when power fails



IMPORTANT: In the event of a power failure, the Latch relay uses continuous battery power and will deplete the battery more quickly than the coil relay.

1. Press and hold  and . **FUNC 1** displays.
2. Press  to scroll to the **Output**.
3. Press . The current setting is displayed.
4. Press  to toggle between **Coil** and **Latch**.



NOTE: The display brightness changes when each setting is displayed.

5. Press  when the desired setting is displayed. **B.LIFE** displays.
6. Press  to exit setup and store the settings.

4.7 Battery Life – Optional

Select either Standard (**Stand**) or Long (**Long**).

In **Long** battery life mode, the system is placed into a sleep state for several seconds at a time if there is no change in tension. This disables the display in order to reduce power consumption and increase battery life. After several seconds, the MSI-8004HD will wake up to check for any changes in tension. If there is a change in tension, the unit stays awake. The unit also stays awake if it is in configuration mode.

Although long battery life mode can significantly increase battery life, performance is better in standard battery life mode.

1. Press  and  simultaneously. **FUNC 1** displays.
2. Press  to scroll to **B.LIFE**.
3. Press . The current battery life setting displays.
4. Press  to toggle between settings.
5. With desired setting displayed, press  to select. **Stand** displays.
6. Press  to save and exit to weighing mode.
- 7.

4.8 Total Mode

For the accumulation of multiple weighments, the Total function uses the displayed load, so gross and net readings can be added into the same total.

There are four modes of totalizing, a manual and three auto modes.

All modes require that the weight on the scale return below 0.5% (relative to full scale) of **Gross Zero** or **Net Zero** before the next weighment can be added. Applied weight must be $\geq 1\%$ of full scale above **Gross Zero** or **Net Zero** before it can be totaled.

Manual Total

Manual Total (TTL) adds a current weight to a previously accumulated value manually. To add weight to the total it must be greater than 1% of capacity and not yet totaled. This assures that a weight on the scale is only added to the total once.

1. Program a **F-key** to **TOTAL** (Section 4.3 on page 16).
2. With the weight to be added on the scale, press **F-Total**. The acknowledge LED blinks to indicate the weight was accepted and the **TOTAL** annunciator lights. Then the total weight is displayed for five seconds and the number of samples is displayed for two seconds.
3. Repeat Step 1 and Step 2 until all weight samples have been added.



NOTE: Total Mode will not function while the scale is in motion, ensure   is on. If the system fails to achieve stable readings, increase the filter setting or increase the size of the scale division (d) in the Init Cal procedure.

The F-Total functions as View Total only until the 1% threshold is exceeded to allow the addition to the total value.

Auto Total

This mode has three variations which are programmed in the Setup menu.

Program an **F-key** to **AUTO TOTAL**, it functions as **Auto Total On / Auto Total Off** (Section 4.3 on page 16).

Setpoint	Description
R.LoAd	Auto Load – Ensures any settled load above the Rise Above threshold will be automatically totaled; The scale must fall below the Drop Below threshold before the next total is allowed
R.LASt	Auto Last – Takes the last settled weight to auto total with; The total occurs only once the scale goes below the threshold; This allows the load to be adjusted without a total occurring; Once the load is removed, the scale uses the last settled reading for total
R.hiGh	Auto High – Uses the highest settled reading; This is useful for loads that can not be removed all at once

Table 4-3. Auto Load Selections

Set Total Mode

1. Press  and  simultaneously. **FUNC 1** displays.
2. Press  to scroll to **TOTAL**.
3. Press . The currently saved filter mode displays.
4. Press  to scroll through the choices.
5. With choice displayed, press  to select. **FILTER** displays.
6. Press  to exit setup and store the settings.

Reset Total Load

To reset the total load to zero, press **Fx-Total** again and while the total load is being displayed, quickly press .

4.9 Filter Setup

The filter settings are used to stabilize the weight in an unstable condition. Increasing the filter will improve the stability, however settling times will be longer. The MSI-8000HD employs algorithms that speed up large weight changes while still controlling vibration even with high filter settings.

Use the following steps to set up filtering.

1. Press  and  simultaneously. *Func 1* displays.
2. Press  to scroll to *FILTEr*.
3. Press . The currently saved total mode displays.
4. Press  to scroll through the choices.
5. With choice displayed, press  to select. *unit* displays.
6. Press  to save and exit to weighing mode.

4.10 Unit

1. Press  and  simultaneously. **Func1** displays.
2. Press  to scroll to **Unit**.
3. Press  **Unit** displays with lb or kg in the lower right of the display area.
4. Press  to toggle between lb and kg.
5. With the desired choice displayed, press  to select.
6. Press  to save and exit to weighing mode.

5.0 Calibration

This section provides an overview of MSI-8000HD RF Indicator calibration instructions.

The MSI-8000HD RF Indicator can be used for calibrating MSI ScaleCore-based crane scales and dynamometers, including MSI-3460 Challenger 3, MSI-4260 Port-A-Weigh or MSI-7300 Dyna-Link 2.

They can be calibrated using standard precision test weights. It is required that the weight used is at least 10% of full capacity in order to achieve rated accuracy.

When adequate test weights are not available, the scale/dynalink can be calibrated using a constant calibration (C - CAL) (Section 5.2.2).

5.1 Calibration Switch

To calibrate a scale that is in HB-44 or R-76 standard, the calibration switch must be pressed to put it in the calibration mode.




Figure 5-1. Press Configuration Switch

1. Remove screw and washer from the top of the unit.
2. Insert a small non-conductive tool into the hole far enough to press the switch. **CAL** is displayed.



IMPORTANT: Care should be used when pressing the configuration switch to avoid damage to the switch and other board components.



NOTE: The MSI-8000HD Remote Display will need to be resealed after calibration is complete, to be in compliance with legal for trade operation.

5.2 Initial Calibration

Initial calibration is used to setup units, capacity and resolution (d) required for the load cell or after a calibration reset.

1. Press  and  simultaneously. $\square RL$ displays.
2. Press the programmed **F-Key** to scroll to the load cell to be calibrated.
3. Press , unit displays.
4. Press . The default units are displayed.
5. Press  to scroll through the available units.
6. With desired unit displayed, press  to select. $\square AP$ is displayed.
7. Press . The default capacity is displayed.
8. To enter a different capacity, press .
9. Press  to scroll through numbers and  to save the selected numbers.
10. When all numbers have been selected, press  to store the number. d displays.
11. Press . The default display divisions are displayed.
12. Press  to scroll through the available display divisions.
13. With desired display division displayed, press  to select. $\square L d$ displays.
14. Proceed with the routine calibration in [Section 5.2.1 on page 25](#), starting with step 2.

5.2.1 Routine Calibration

For maintenance and routine calibration use the following steps.

1. Press the configuration switch. $\bar{C}AL$ is displayed.
2. Press , $uNLd$ displays.
3. Remove all weight from the scale.
4. Press , $\bar{0}$ flashes.
5. Press , $PASS$ displays momentarily, then $Ld1$ displays.
6. Load the scale with a precision test weight, for best accuracy a test weight of 10% of capacity or more is recommended.
7. Press , the capacity of the scale flashes.
8. To enter a test weight other than the capacity, press .
9. Press  to scroll through numbers and  to save the selected numbers.
10. When the correct weight is displayed, press  to store the number. If cal value is within limits, $PASS$ displays momentarily then $Ld2$ displays.
11. Press  to enter the second load.
12. Add load to scale and press .
13. Press , the current weight on the scale flashes.
14. Repeat [Step 4–Step 10](#), up to four loads.
15. When all loads are complete, press  to store the calibrations. $\bar{C}AL'd$ displays.
16. Press  to view the cal number. $\bar{C}-\bar{C}AL$ flashes momentarily followed by the $\bar{C}-\bar{C}AL$ number, record the value, this number will be required if calibrating with $\bar{C}-\bar{C}AL$ ([Section 5.2.2 on page 26](#)).
17. Press . $StorE$ displays momentarily, then $SEtUP$ displays.
18. Press  to exit calibration. $StorE$ displays momentarily, then the unit returns to weigh mode.

Repeat this procedure to calibrate all scale/Dyna-Link 2's that are connected to the MSI-8000HD remote display.

5.2.2 C-Cal Calibration

When adequate test weights are not available, the scale can be calibrated using a cal number calibration which is referred to as C-Cal. To use C-Cal, a factory generated C-Cal number must be known. Rice Lake supplies replacement load cells with the C-Cal value stamped on the serial number label. When a calibration is performed with test weights, a new C-Cal is generated.

The C-Cal number must be known prior to starting this procedure. Rice Lake prints this number on the serial number label. C-Cal reduces slightly the accuracy of the system and is intended for non-critical use only. For highest accuracy, calibrate with precision test weights.

1. Press  and  simultaneously. **CAL** displays.
2. Press  to scroll to **C-CAL**.
3. Press , **UNLD** displays.
4. Remove all weight from the scale.
5. Press , **0** flashes and **PASS** will display momentarily then **C-CAL** displays.
6. Press , the last known **C-CAL** displays.
7. To accept the number displayed press . Skip to [Step 10](#).
To enter a different **C-CAL** number, press .
8. Press  to scroll through numbers and  to save the selected numbers.
9. When the correct number is displayed, press  to store the number. **PASS** displays momentarily then **CAL'd** displays.
10. Press . **STORE** displays momentarily then **SETUP** displays.
11. Press  to exit calibration. **STORE** displays momentarily then the unit returns to weigh mode.

5.3 Setup

Setup is used to set the desired Industry Standard and Auto Zero Maintenance (AZM).

1. Press the configuration switch ([Section 5.2 on page 24](#)). ϵRL displays.
2. Press  to scroll to $SEtUP$.
3. Press , $SEAnd$ displays.
4. Press , the current standard setting displays.
5. Press  to scroll through calibration standards selections. See [Section 5.2.1 on page 25](#) for details of the standards.
6. When desired option is displayed press . $Auto0$ displays.
7. Press  to enter Auto Zero Maintenance.
8. Press  to toggle between On/OFF .
9. Press  to set on or off. $0. P- uP$ displays.
10. Press  to enter zero on power-up.
11. Press  to toggle between On/OFF .
12. Press  to set on or off. $SEAnd$ displays.
13. Press  to return to ϵRL .
14. Press  again to exit calibration. $SEOrE$ displays momentarily then the unit returns to weigh mode.

5.3.1 Standard Settings

Below are the four selections in the standards menu.

Standard Type	Description
Industrial $indus$	The common setting for the MSI-8000 RF Indicator; With the Industrial standard, you have full range zero, access to units switching, filters, and peak hold
Handbook 44 $hb44$	Sets the scale to enable only approved features per the NTEP HB-44 rules and regulations; Access is denied to Peak Hold, and the zero range may be limited; The Filter menu is moved to the Cal Setup Menu, so filters are only accessible through the Cal Seal
R-76 $r-76$	Sets the scale to enable only approved features per OIML R-76; only kg weight units are available; the zero range is limited to 4% (-1 to +3% relative to calibrate zero); NET/GROSS function is temporary; once NET weight is established, pushing an F key set for NET/GROSS will cause a maximum 5 second display of the GROSS weight; clear the Tare to display GROSS weight constantly; other metrological aspects are changed to meet R-76 requirements; only stable weights may be printed; negative weight display is limited to -20d
One Unit $1 unit$	The one unit standard is exactly the same as Industrial, except unit switching is inhibited; This is useful for Metric only countries; Another use of the One Unit standard is to allow the scale to be calibrated in units other than lb or kg, since conversions are eliminated

Table 5-1. Standard Settings Parameter

Contact Rice Lake Weighing Systems for more information on the standards settings.

5.4 Reset the Load Cell Calibration

To completely remove current calibration, a calibration reset must be performed.

1. Press the **F-Key** set to scan to scroll to load cell to reset.
2. Press and hold the calibration switch then press . **rESEt** flashes.
3. Press , **StorE** flashes.
4. Press  to reset the calibration for current load cell. **LRd** displays.
5. Proceed with the Initial Calibration ([Section 5.2 on page 24](#)).

 **IMPORTANT:** Pressing  resets all indicator settings to the original factory settings.

 **NOTE:** Press the  to cancel reset and return to the previous menu.

5.5 Auto Zero Maintenance (AZM)

An auto zeroing maintenance mechanism is used to adjust the zero reading to the center-of-zero. The center-of-zero is defined as the weight reading within 1/4 d of zero. AZM continuously adjusts zero to maintain the center-of-zero. It is recommended that AZM is on to maintain the highest accuracy.

There are circumstances when it should be turned off. This can happen when minor variations of weight occur while picking up scale attachments and the variations fall within the AZM capture window. The AZM capture window (usually 1 d) and capture time (usually 8 seconds) can be adjusted by Rice Lake Weighing Systems to meet custom requirements.

The settings of AZM are dictated in Legal for Trade standards and cannot be adjusted.

Use the following steps to set up Legal for Trade standard settings.

1. Enter **Configuration** mode ([Section 5.1 on page 23](#)). **LRd** displays.
2. Press  to scroll to **SEtUP**.
3. Press , **StAnd** displays.
4. Press  to scroll to **AutoZ**.
5. Press , The current setting is displayed.
6. Press  to toggle between **On** or **OFF**.
7. Press , **StorE** displays.
8. Press  twice to save settings. **StorE** displays briefly and exits setup.

5.6 Zero Power Up (0.P-UP)

This feature will cause the unit to automatically zero after the unit is turned on. Default is OFF.

1. Enter **Configuration** mode ([Section 5.1 on page 23](#)). *LR* displays.
2. Press  to scroll to *SEtUP*.
3. Press . *SEtRnd* displays.
4. Press  to scroll to *0.P-UP*.
5. Press . The current setting is displayed.
6. Press  to toggle between *On* or *OFF*.
7. When desired value is displayed, Press . *FILtR* displays.
8. Press  twice to save settings. *SEtORF* displays briefly and exits setup.

6.0 Communications

This section provides an overview of MSI-8000HD RF Indicator communication instructions.

6.1 Communications Setup

The MSI-8000HD can communicate with peripheral devices using 802.15.4, or 802.11/b, g, n Wi-Fi. Only one communication type can exist at a time. The 802.15.4 transceiver is used to communicate between the MSI-8000HD and other connected ScaleCore devices. The 802.15.4 transceiver is also capable of connecting to any supported device with an 802.15.4 Modem. 802.15.4 operates in the 2.4 GHz ISM band and does not require the end user to obtain a license. 802.15.4 can coexist with other 2.4 GHz systems if caution is taken to isolate antennas at least 10' (3 m) from the crane scales. The 802.11 Wi-Fi option communicates directly with a standard RF access point. This option is covered by the Wi-Fi for ScaleCore User Guide."

Name	Description	Recommended Number Range
ScaleCore ID	Used to identify each device in a piconet, its range is 0–254 and cannot be duplicated within the same RF channel	20–30
RF Channel	Establishes the base network that all interconnected devices must match	12–23
Network ID	A 64-bit number that all interconnected devices must match, do not use a small number to avoid other 802.15.4 transceivers that default to a network ID of 0	Maximum of six digits with a range of 0–65535

NOTE: For all devices that must interconnect, the RF channel and network ID must match. The ScaleCore ID must be unique. The MSI-8000HD Indicator that is the weight source should be set to a ScaleCore ID of 0. If other source devices are added, they can be added in sequence.

NOTE: It is possible to have multiple separate MSI ScaleCore RF networks in the same location. Each device on the same network must be on the same channel, but for best performance different ScaleCore networks should be on different RF channels.

Table 6-1. Piconet Setup Ranges

6.2 Communications Menu

To enter the Communications menu, press **F1** and **F3** at the same time. **bL5Y** flashes momentarily before entering the communications menu.

Parameters	Choices	Description
Print	–	Print – Prints a ticket if connected to a printer
RF	–	Radio Frequency (Table 6-8 on page 34)
Add ing	End.Ld	Total Loading - The total number of sensors ranging between 1-4; Default is 1
	Add.Ld	Total Sensors ALL – Sum of all remote devices Pair5 – Sum in pairs (requires four remotes) both – Sum in pairs plus grand total uSEdEF – Programmed using a computer program such as Scope oFF – Summing is disabled

Table 6-2. Communications Menu Parameters



NOTE: Transmission strength should be set to the lowest setting possible to achieve the transmission required. Both the scale/Dyna-Link and the 8000 should be set at the same transmission strength setting.

Setting	RF Power Level	Transmit Current	Note
0	10 dBm	137 mA	Lowest Transmission Power
1	12 dBm	155 mA	Default on 7300s and 8000s
2	14 dBm	170 mA	—
3	16 dBm	188 mA	—
4	18 dBm	215 mA	—

Table 6-3. Transmission Strength Settings

6.3 Printer Setup

The RS-232 communications port is capable of outputting load data. All of the RF linked weight device weight modes are available in user formatted form. The control mode program is what controls the MSI-8000HD to print and is described in [Section 6.3.1](#).

The communications port settings are independent of any print settings in connected scales.

Choices	Description
LS _{ET} NR	Print Setup – Select the channel the port will be used with; Options: 0, 1, 2
OUTP _{UT}	Port Selection – Select the port to use for communication with the printer; Options <i>Port 0</i> , <i>RF</i> , <i>Port 2</i>
STRNG	String Setup – Print string format number entry screen (Table 6-7 on page 32)
CTRL	Print Control Options – <i>USER</i> , <i>LOAD</i> , <i>CONT</i> , <i>OFF</i> (Table 6-5)
RATE	Output Rate – Print string output rate number entry screen (0–65536 seconds)

Table 6-4. Print Setup Parameters

6.3.1 Control Modes

The user can select four control modes. The control modes are described in [Table 6-5](#).

Mode	Description
User	Printing is controlled by pressing the F3 key
Load	One print occurs when a stable load is read, the scale must then return to near zero before another print will occur NOTE: Other configurations of load are available using the ScaleCore Connect. It can be downloaded from the Rice Lake Website
Continuous	The unit will continuously output the data at a rate specified in the rate parameter (up to 65,535 seconds); Setting the interval to 0 will set an interval as fast as the system can go
Off	Printing is disabled; Power consumption is lower with the print off

Table 6-5. Control Modes

6.3.2 Standard Print Strings

Commands that can be used to format gross, net and print strings are shown below.

Command	Description
<T>	Load data
<U>	Units
<M>	Load mode (lb/kg)
<CRLF>	Carriage return line feed
<SP>	Space

Table 6-6. Standard Print Strings

Load	Parameter	Description
1	Current load	Fixed output length: 16; Leading zeros suppressed except for the least significant digit (LSD) <TTTTTT><SP><UU><SP><MMMMM><CRLF>
2	Net load	Fixed output length: 16; Leading zeros suppressed except for the LSD <TTTTTT><SP><UU><SP>NET><SP><SP><CRLF>
3	Gross load	Fixed output length: 16; Leading zeros suppressed except for the LSD <TTTTTT><SP><UU><SP>GROSS><CRLF>
4	Tare Weight	Fixed output length: 16; Leading zeros suppressed except for the LSD <TTTTTT><SP><UU><SP>TARE><CRLF>
5	Total Weight	Fixed output length: 16; Leading zeros suppressed except for the LSD <TTTTTT><SP><UU><SP>TTL><CRLF>
6	Number of Samples Totaled	Fixed output length: 16; Leading zeros suppressed except for the LSD <SP><SP><SP><SP><SP><SP><SSSSSS><SP><T-CNT><SP><CRLF>
7	Rice Lake/Condec	<STX><P><W7.><U><M><S><CR><LF>
8/9	Carriage Return/Line Feed	Used to add a space between print records <CRLF>

Table 6-7. Standard Print Strings

Combinations of the standard print strings can be entered in the string number entry screen.

Example: To get a Net, Gross, Tare printout with a space between records, enter 2349.

The ScaleCore Connect application can also be used for custom output strings, it can be downloaded from the Rice Lake website.

The serial output is configured as 9600 baud, Xon/Xoff handshaking, no hardware handshaking, 1 stop bit, no parity.

Other baud rates are possible by special order only.

6.3.3 Printer Output Setup

Use the following steps to set up the printer output.

1. Press  and  at the same time. *Print* displays.
2. Press . *Listener* displays.
3. Press  to scroll to *String*.
4. Press . The current print string number is blinking.
5. Press  to scroll through the numbers and press  to save and move to the next number.

Example: If Net, Gross and Tare are to be used for the print format, the entry required would be 2349. The 2 is net, 3 is Gross, 4 is tare and 9 inserts a space before the next print output.

6. Once all numbers are set, press  to save the print mode. *Enter* displays.
7. Press . The current control mode displays.
8. Press  to scroll through the options.
9. When the desired control mode is displayed, press . *Rate* displays.



NOTE: If control mode has been set to continuous, press  then proceed to [Step 13](#).

10. Press . The current print rate displays.
11. Press  to scroll through the numbers and press  to save and move to the next number.
12. When number is correct, press . *Listener* displays.
13. Press . The current listener value displays.
14. Press  to scroll through the numbers and press  to save and move to the next number.
15. Once the desired value is displayed, press  to save. *Output* displays.
16. Press . The current output displays.
17. Press  to scroll through the options.
18. Once the desired output is displayed, press  to save. *String* displays.
19. Press  three times to exit, *Stand-By* displays briefly, then the unit returns to weigh mode.

6.4 RF Network Setup

Allows the setup of the radio.

Mode	Description
On . OFF	Enable radio – On/Off, affects continuous mode only
Scale ID	ScaleCore ID – Range 1–254, (20–30)
Channel	RF Channel – Range 12–23
Network ID	Network ID – Range 0–999999
Transmission Strength	Transmission Strength – Range 0–4 (Table 6-9)
TYPE	Allows the selection of radio card that is being used; For cards other than XBee/802.15.4 use the other selection: Other, ZBEE
hold	When set to On, the radio continues to use power; This will use the battery power faster; Default is set to OFF Hold must be enabled when using a Rugged Remote to turn on the MSI-8000HD Indicator

Table 6-8. RF Setup Parameters



NOTE: Transmission strength should be set to the lowest setting possible to achieve the transmission required. Both scale/Dyna-Link and MSI-8000 RF Indicator should be set at the same transmission strength setting.

Setting	RF Power Level	Transmit Current	Note
0	10 dBm	137 mA	Lowest Transmission Power
1	12 dBm	155 mA	Default on 7300s and 8000s
2	14 dBm	170 mA	–
3	16 dBm	188 mA	–
4	18 dBm	215 mA	–

Table 6-9. Transmission Strength Settings

Use the following steps to set up the RF menu parameters.

- Press **F1** and **F3** at the same time, **Print** displays.
- Press **F2** to scroll to **RF**.
- Press **F1**. **On . OFF** displays.
- Press **F1**. The currently saved parameter is displayed.
- Press **F2** to toggle between on and off.
- With **On** displayed, press **F1** to select. **OFF** is used when the 8000 is hardwired to a Dyna-Link. **Scale ID** displays.
- Press **F1**. The current ScaleCore ID displays.
- Press **F2** to scroll through numbers and **F1** to save the selected numbers.
- When number is correct, press **F1** to store the number. **Channel** displays.
- Press **F1**. The current channel setting displays.
- Press **F2** to scroll through numbers and **F1** to save the selected numbers.

12. When number is correct, press  to store the number. *net* displays.
13. Press . The current Network ID displays.
14. Press  to scroll through numbers and  to save the selected numbers.



NOTE: Rice Lake Weighing Systems recommends at least a four digit for the Network ID, to ensure there are no conflicts with any other 802.15.4 networks.

15. When number is correct, press  to store the number. *Strength* displays.
16. Press . The current Strength setting displays.
17. Press  to scroll through 0–4.
18. When the number is correct, press . *TYPE* is displayed.
19. Press . The current type displays.
20. Press  to scroll through values.
21. With selected value displayed, press . *hold* displays.
22. Press . The current setting displays.
23. Press  to toggle between on and off.
24. When the selection is correct, press  to store the number. *On . OFF* displays.
25. Press  to save and exit the RF menu.
26. Press  to exit to the communication menu.

6.5 AD Inputs

Changing an MSI-8000HD indicator to remote display requires reprogramming with the remote display software. Contact your Rice Lake Weighing Systems dealer for more information.

6.5.1 Set the Total Number of Load Cells

1. Press  and  at the same time. *Print* is displayed.
2. Press  to scroll to *net*.
3. Press . *Load* is displayed.
4. Press . The Load Totaling setting displays.

5. Press  to scroll through numbers and  to save the selected numbers.
6. When correct number of scales/Dyna-Link 2 attached (2-4) is displayed, press . This number does not include the MSI-8000HD or any modems. *LLL .rd* displays.
7. Press . The Load Totaling setting displays.
8. Press  to scroll through numbers and  to save the selected numbers.
9. Press . *Load* displays.
10. Press  twice to exit to the weighing mode.

6.5.2 Scan Weight Inputs

1. Program **F1** to the *Scan* function, and **F2** to the *LLL .rd* function for summed sensor readings ([Section 6.5.3](#)).
2. The current channel is displayed, press  to change to the next channel. The scan channel number is displayed briefly, then the scan channel weight is displayed.
3. Press . In a two sensor system the scan returns to the first channel (0).

6.5.3 Load Totaling Settings

There are four different types of load totaling modes and are explained below.

All

All channels are added together, press *F-LLL .rd* to view the sum of all sensors connected. Pressing *FH-LLL .rd* again confirms that the summed channels are being displayed, by briefly displaying *LLL .rd* (total remote sensor devices).



If the sum is the only thing to be observed, disable the Scan function key using the function key setup menu ([Section 4.3 on page 16](#)).

Pairs

Used with four sensor systems, scrolling through the channels with *FH-LLL .rd*, they will be presented as separate weights first and then as pairs. This display is preceded by the LCD message *PR 1* and *PR 2*.

Both

This mode displays both the pair totals and the overall total. Each press of *FH-LLL .rd* scrolls through the summed combinations. First *PR 1*, then *PR 2* then the sum of all connected sensors is displayed.

Off

Sensor summing disabled. A function key set to *LLL .rd* is unnecessary.

1. Program an F-key to the *LLL .rd* function ([Section 4.3 on page 16](#)). The current channel is displayed.
2. Press *Fx-LLL .rd*. *ALL* is displayed briefly, then the summed total.
3. Continue pressing *Fx-LLL .rd* to view all enabled sum types.

6.6 Zero and Tare in Multiple Load Cell Systems

The channel displayed is considered the **Focus Channel**. Pressing  or  only affects the displayed channel.

When displaying summed channels, ZERO or TARE commands are sent to all devices that contribute to the displayed weight.

*Example: If in the Both modes, and displaying pair 1 (sum of SC0 and SC1), pressing **ZERO** will zero only SC0 and SC1. If displaying the grand total using the ALL mode then pressing **ZERO** will zero all connected sensors.*

6.7 Communications Port Hardware

The MSI-8000HD RF Indicator RS-232 communication port is used for software updates, connecting to a remote display and for connecting to any RS-232 device.




Figure 6-1. Standard Adapter Cable (PN 148624)

Connector – M12 industrial connector. An adapter cable (PN 150964) is required to connect the MSI-8000HD RF Indicator to a computer. This adapter cable converts the 8000 connector to a standard D9 serial connector. The 503489 cable can be converted to DTE by using a Null Modem adapter.

Data Configuration – The data output is fixed at 8-1-N.

Baud Rate – Port1 baud rate is fixed at 9600. Port2 baud rate is fixed at 38.4k.

Handshaking – No hardware handshaking is supported. Xon/Xoff software handshaking is always on.

This configuration plugged into a standard DTE connector disables Comm Port 2. Turn Comm Port 2 off using the Comm Port menu.

An unterminated cable is available (PN 143348) for wiring a connector to the M12 connector found on the MSI-8000HD RF Indicator.

The following diagrams show how to wire standard D9 connectors to access Communications Port 1 or Communications Port 2:




Figure 6-2. Communications Port 1 Wiring




Figure 6-3. Communications Port 2 Wiring

Wiring the shield drain to the metal shell of the connector is recommended, however, in some circumstances it may be necessary to disconnect the shield drain wire at the connector frame to prevent ground loops which can cause unstable readings. In extreme cases it may be necessary to use an isolated RS-232 interface.




Figure 6-4. Connection with Y Adapter

6.8 Relays

The MSI-8000HD can be equipped with up to eight relays for process control or safety systems.

Two independent relays are factory installed and are wired out to 4 pins on a M12 connector.

The connecting cables are shown in the table below:

Part No.	Description
144440	PVC 4 m, rated to 250 VRMS, 4 A
	PVC 10 m, rated to 250 VRMS, 4 A
Alternately use a field wireable connector	
156256	Straight for cable 4-6 mm OD
	Right angle for 4-6 mm
	Straight for cable 6-8 mm OD
	Right angle 6-8 mm OD

Table 6-10. Relay Connector Cable Part Numbers




NOTE: The MSI-8000HD indicator can also be equipped with an eight relay expansion. The relays for the expansion pack are accessed through the terminal blocks on the backside of the MSI-8000HD. See [Section 6.8.2 on page 40](#).

6.8.1 Relay Options

Relays are normally open (1 Form A). Specifications are listed below.

Relay Type	Description
AC/DC coil relay	- AC/DC Coil Relay: 144520 PA1a-5 V. 4 A Fuse: 144307 - AC Rating: 250 VAC at 5 A (limited by connector/cordset rating to 5 A continuous) - DC Rating: 5 A @ 30 VDC, 0.5 A at 100 VDC - Best choice for 90% of applications.
AC/DC SSR (solid state relay) - 60 V	- Better for battery powered units and mates well with 24VDC industrial power supplies - AC/DC SSR 60 VPK, 2.7 A: 13178 AQZ202D. 2 A Fuse: 144319
AC/DC SSR - 120V	- For 115VAC operation when SSRs are preferred. - AC/DC SSR 200 VPK. 0.9 A: 13180 AQZ207D. 0.75 A Fuse: 155221
Other available relays	- AC/DC SSR 100 VPK, 2 A: 13179 AQZ205D. 1.5 A Fuse: 155220 - AC/DC SSR 400 VPK, 0.45 A: 13181 AQZ204D. 0.375 A Fuse: 155222 (use limited to 250VRMS due to connector and cordset limitations) - DC Only SSRs - DC SSR 60 VPK, 4 A: 13182 AQZ102D. 3 A Fuse: 155223 - DC SSR 200 VPK, 1.3 A: 14566 AQZ107D. 1 A Fuse: 160448 NOTE: Normally open relays (1 Form A) can be made to function as normally closed (1 Form B) by programming the setpoint as a less than type. If the 8000HD is turned off or loses power, they will open.
One 1 Form B closed SSR	AC/DC SSR 400 VPK, 0.5 A: 14628 AQZ404. 0.5 A Fuse: 144583 (use limited to 250 VRMS due to connector and cordset limitations) NOTE: Requires a minor modification on the Relay board and can only be ordered by contacting Rice Lake Weighing Systems (Section 6.8.2 on page 40).

Table 6-11. Relay Options



6.8.2 Extended Relay Kit – Optional




Figure 6-6. Extended Relay Kit:

Part No.	Description
172502	8-CH 0.9A 200VPK SSR FORM C
172501	8-CH 3A 60VPK SSR FORM C
172500	4-CH 3A 60VPK SSR FORM C
172498	8-CH 0.9A 200VPK SSR
172497	8-CH 3A 60VPK SSR
172495	8-CH 12A 5V RELAYS MOMENTARY
172494	4-CH 0.9A 200VPK AC/DC SSR
172493	4-CH 3A 60VPK AC/DC SSR
172492	4-CH 5V MOMENTARY
172490	4-CH 5V LATCHING RELAYS
171676	8-CH 12A RELAYS LATCHING

Table 6-12. Expanded Relay Option Kits

6.9 Radio Compliance

All radio options meet FCC and international radio compliance per the certification information listed in this section.

These modules may have additional international certifications that are not listed in this section.

Please contact Rice Lake Weighing Systems if you require operation in a jurisdiction that is not listed.

6.9.1 802.15.4 (XBee 3 and XBee 3-PRO)

FCC Statement

Contains FCC ID: MCQ-XBEE3

International Certifications

Canada: Radio Certificate Number: IC 1846A-XBEE3

Australia: RCM

Brazil: ANATEL 06329-18-01209

EU (XBee 3 only): Yes, when used with CE approved products

Japan (XBee 3 only): R210-119309

Mexico: IFETEL (IFT) RCPDIXB19-1820

South Korea (XBee 3 only): R-C DIG-XBEE3

6.9.2 802.15.4 (XBee 2SC)

FCC Statement

Contains FCC ID: MCQ-S2CTH

International Certifications

Canada: Radio Certificate Number: IC 1846A-S2CTH

Australia: RCM

Brazil: ANATEL 0616-15-1209

EU: Yes, when used with CE approved products

Japan: R210-105563

Mexico: IFETEL (IFT) RCPDIS219-1821-A1

South Korea: MSIP-CRM-DIG-XBee-S2C-TH

6.9.3 Wi-Fi

FCC Statement

Contains FCC ID: T9J-RN171

International Certifications

Canada: Radio Certificate Number: IC 6514A-RN171

Korea: Radio Certificate Number: KCC-CRI-029-RN-171

Europe: The product is compliant with the following standards and/or other normative documents:

- EN 300 328 : V1.8.1 (2012)
This product is compliant with the following standards and/or other normative documents:
Safety (article 3.1A) EN 60950-1:2006+A11:2009+A1:2010+A12:2011
EMC (article 3.1b) EN 301 489-1 : V1.9.2 (2011) In accordance with the specific requirements of ETSI EN 301 489-17: V2.2.1 (2012)

6.9.4 WPAN

FCC Statement

Contains FCC ID: T9J-R41-1

International Certifications

Canada: Radio Certificate Number: IC 6514A-RN411

Europe: This product is compliant with the following standards and/or other normative documents:

- EN 300 328-1
- EN 300 328-2 2.4GHz

6.9.5 FHSS (Frequency Hopper Spread Spectrum)

FCC Statement

Contains FCC ID: HSW-DNT24

International Certifications

Canada: Radio Certificate Number: IC 4492A-DNT24

ETSI Certified

6.10 Antenna Options



NOTE: To meet FCC licensing rules, use only antennas supplied or recommended by Rice Lake Weighing Systems.

Antenna placement is critical to problem-free use of the system.

- Ensure a relatively clear transmission path exists between the devices to be connected; Radio signals travel primarily by line of sight (LOS), obstructions between stations may degrade the system performance
- When using the long range antenna, mount the antenna on an elevated structure to ensure that you have a clear LOS transmission path; This will ensure the antenna will clear surrounding obstructions; Do not provide a ground plane for the antenna
- Fixed station locations often benefit from directional antennas when the location of the other components of the RF network are fixed and/or in the same direction; Never use a directional antenna on a mobile system
- If using the standard antenna, ensure the antenna is not blocked by any metal; Transmission is good through most kinds of glass so mounting a meter next to a window will work fine; If there is no clear line of sight place to mount the receiving device, consider switching to the long range antenna so the antenna can be set up remotely
- The standard and long range antennas are vertical plane devices; They should be vertical, pointing up or down, when high off the ground (like the underside of a large bridge crane); Do not mount them sideways; The long range 9 dBi antenna is particularly sensitive to off axis mounting; Use a level to ensure the antenna is exactly 90° perpendicular to the earth
- Do not mount an omni-directional antenna next to metallic or concrete surfaces; This can result in reflections and undesired RF characteristics; Use a corner reflector instead
- After installation, seal the antenna connection with an adhesive heat shrink boot; Failure to seal the antenna may result in liquid destroying the antenna and device it's connected to



NOTE: Rice Lake Weighing Systems does not recommend extending the coaxial cable beyond three meters.

At 2.4 GHz more loss will result from coax losses than are gained by raising the antenna. If the antenna must be extended, use a very low loss 50 ohm coax such as RG-214, RF-195, or other low loss varieties.

For very short extensions (<1m), cables made with RG-316 are suitable.

6.10.1 Available Antennas

Standard Antenna

The standard antenna is an articulated 1/2 wave 2 dBi gain design with a standard TNC connector that mounts directly on the enclosure.

This antenna and coax connector, though resistant to water, is not water-proof. Seal the TNC base with an adhesive heat shrink boot if this antenna might be exposed to rain or other weather conditions where it could get wet.

This antenna must be vertically oriented and is suitable for most short to medium range applications.




Long Range OMNI 9 dBi Antenna

This omni-directional high gain antenna is remotely mounted with a low loss coaxial cable and increases the range up to four times.

The antenna must be vertically mounted. The vertical Beamwidth (-3dB point) is 14 degrees.

This antenna is supplied with a 10 foot (3m) coax cable pre-attached. The 10-foot cable allows placement of the antenna above the unit for ease of clearing possible obstacles to data transmission. It is also available with an N connector for applications requiring longer coax cable lengths.



Vehicle Mount Whip Antenna

The vehicle mount whip antenna mounts directly to the roof of mobile vehicles and is weatherproof.

This 5 dBi gain whip mounts in a 3/4" hole on the roof of the vehicle.

The mount includes 17' of low loss coax terminated in a TNC connector.



YAGI Antenna

For maximum range, a 14 dBi gain Yagi Antenna is available by special order. Please contact Rice Lake Weighing Systems for details.



Corner Reflector Antenna

Corner reflector antennas are often the best choice for a wall mounted antenna. Rice Lake Weighing Systems offers a 14 dBi and a 9 dBi corner reflector.



14 dBi Corner Reflector



9 dBi Corner Reflector

Patch Antenna

The patch antenna is for applications where the standard antenna is vulnerable to physical damage or outdoor applications.

The patch antenna is mildly directional which requires more care in antenna placement for long range applications.

Patch antennas are available by special order only. Please contact Rice Lake Weighing Systems for details.

6.11 Direct Download into Excel Spreadsheet

Allows for direct download of data from the MSI-8000HD into Excel.

1. Hook the serial cable (PN 148624) from the RS-232 port at the bottom of the unit into the Able Cable (PN 119919).
2. Plug the USB connector on the Able Cable into a PC serial port.
3. Open Excel Spreadsheet on the connected PC.



NOTE: *Excel must be open and active on the screen for the data to download.*

4. Click a box on the opened excel spreadsheet. This is where the data will be recorded.
5. If in Continuous Mode, data will begin displaying when Able Cable is plugged in. If in User Mode, press F3 to Print for data to display.

For continuous data output, configure the MSI-8000HD as follows for printing:

1. Program Listener to **0**.
2. Program Output to **Port 0**.
3. Program String to Output wanted Data.
4. Program Control to be outputted continuously.
5. Program the Data output Rate to output at interval needed for accurate data collection.

For output only when **Print Key** is pressed, configure the MSI-8000HD as follows for printing:

1. Program Listener to **0**.
2. Program Output to **Port 0**.
3. Program String to Output wanted Data.
4. Program Control to **User**.
5. Program the Data Output Rate to output at interval needed for accurate data collection.



Custom Print Output strings are available when using ScaleCore Connect. See Section 5.8 of the User's Manual and the ScaleCore Connect Software Manual for details.

The Scale Core Connect Program is included on the CD ROM that is included with the MSI-8000HD when purchased from MSI/RLWS, or can be downloaded at www.ricelake.com/8000hd.

7.0 Optional Rugged Remote

The MSI-8000HD with an installed RF modem can be controlled with an optional Rugged Remote (PN 173014). The Rugged Remote is a transmit only device that can be used to perform basic scale functions. The range may vary up to 100' or more depending on room conditions and line of sight.

The RF modem in the MSI-8000HD must be configured to accept communication from the Rugged Remote, contact Rice Lake Weighing Systems for pairing requirements.



NOTE: A Rugged Remote is paired to an individual device and cannot be reprogrammed in the field.



Figure 7-1. Rugged Remote

7.1 Operation

The Rugged Remote is paired to a single ScaleCore RF device and replicates the front panel buttons. Slight variations between each device's buttons will result in different operation in the Rugged Remote. See [Table 7-1](#) for corresponding buttons for the Rugged Remote and the connected device.



NOTE: The Rugged Remote can only be paired to a single ScaleCore device. Reprogramming to configure communication to a different ScaleCore device can only be performed at the factory or with the purchase of additional RF modems.

Rugged Remote	MSI-8000HD	Description
		Power
		Zero
		Function 1
		Function 2

Table 7-1. Corresponding Buttons

7.1.1 Power

The Rugged Remote can be enabled to turn on and off the ScaleCore device it is paired remotely. The hold function must be enabled in the MSI-8000HD ([Section 6.4 on page 34](#)).



NOTE: The Hold feature causes the device's modem to stay on and continuously draw from the battery, even when the device is turned off, resulting in decreased battery life.

7.1.2 Zero

Press  to remove small deviations in zero when the MSI-8000HD is unloaded ([Section 3.2 on page 13](#)).

This key is not programmable.

7.1.3 Programmable Function Keys

Tare/F1 and FCN/F2 (pictures of buttons) are programmable in the MSI-8000HD. Function 1 is defaulted to Peak hold and Function 2 is defaulted to Test in the MSI-8000HD. See [Section 4.3 on page 16](#) to configure the MSI-8000HD function keys for Rugged Remote operation.

7.2 Conflict and Jamming Considerations

It is important to understand that only one transmitter at a time can be activated within a reception area. While the transmitted signal consists of encoded digital data, only one carrier of any frequency can occupy airspace without conflict at any given time. This is not to say that there cannot be multiple remote controls for the unit, but rather that two cannot be used simultaneously.

7.3 FCC Compliance

The Rugged Remote has 802.15.4 certification ([Section 6.9 on page 40](#)).

8.0 Troubleshooting and Maintenance

This section provides an overview of MSI-8000HD RF Indicator troubleshooting and maintenance instructions.

8.1 Troubleshooting

Problem	Possible Cause	Solution
The display is blank when the power button is pressed	Discharged battery	Recharge the battery
	Defective battery	Replace the battery (factory replacement only)
	Defective switch or circuit board	Requires authorized service
Display does not function properly/ Front panel buttons do not function normally/scale/Dyna-Link will not turn off	Improperly loaded software	Reinstall the software
	Faulty circuit board	Requires authorized service
	Loose connectors	Requires authorized service
Scale/Dyna-Link does not respond to tension changes	Out of calibration	Calibrate the unit
	Faulty load cell	Replace the load cell
	Load cell connector	Check connectors and wires
The display over ranges below 100% of capacity	Tared tension is added to load to determine overload point	Return to gross tension mode
	Zero requires adjustment	Rezero the scale
	Too much tension/load has been zeroed	Rezero the scale
Display drifts	AZM (Auto 0) is turned off	Turn AZM on
	Rapid temperature changes such as moving scale from indoors to outdoors	Wait until the scale temperature has stabilized
Displayed tension shows a large error	Scale not zeroed before load is lifted	Zero the scale with no load attached
	lb/kg units causing confusion	Select proper units
	Requires recalibration	Recalibrate the unit
Display reading is not stable	Excessive vibration	Increase filtering or increase d in Cal
	Excessive side loading	Improve load train symmetry
	Load cell faulty	Check load cell connections
Display toggles between Error and Load	Load exceeds capacity	Reduce tension immediately
	Faulty load cell or wiring	Check load cell and load cell wiring
Display toggles between Error and Button	A key is stuck or is being held down	Check switches for damage
Weight is on the scale/Dyna-Link and RF Indicator do not match	Units are not paired	See setting the RF Network address procedures
Lo Batt is blinking	The battery is low	Recharge the battery
Unit turns on, immediately off	The battery is low	Recharge the battery
Load will not zero	The system not stable	Wait for stable symbol  to turn on
		Increase filtering for more stability
	Zero out of range	Zero range might be limited; Reduce the tension or use Tare instead
Load will not tare or total	The system not stable	Wait for the stable symbol  to turn on, or if in a mechanically noisy crane, increase the filtering or reduce the size of the scale increment d ; It is also possible to increase the motion window; Contact Rice Lake Weighing Systems if there is a problem getting the MSI-8000HD to zero, tare or total due to stability issues
Setpoint lights blink	Set point enabled and trigger point reached	Disable set points if they are not needed
The manual total does not work	A function key is not set to total	Set up Func1 or Func2 for total
	Tension must be stable	Increase filtering for more stability
The auto total does not work	Load must be stable	Wait for stable symbol  to turn on or increase filtering
	Load thresholds are not reached	Weight must exceed one percent of capacity for auto total to work; Weight must drop below 0.5% of capacity for additional weighments to register

Table 8-1. Troubleshooting

8.2 Error Codes

The ScaleCore Processor in the MSI-8000HD RF Indicator detects errors and generates error codes to aid in troubleshooting.

Error Code	Definition	Comment
LcOFF	LC Disabled	A Load cell was not enabled
2CAL	In Cal	The system is in calibration mode; Do not send commands unrelated to calibration
unCAL	Not Calibrated	System has not been calibrated
 Error LoAd	Overload	Tension/Weight exceeds set capacity +9 d or load cell is damaged or disconnected
 Error UndLd	Underloaded	Tension/weight is more than 20% negative or load cell is damaged or disconnected

Table 8-2. Error Codes

8.3 Service Counters



WARNING: Only a Rice Lake Weighing Systems factory representative can reset the service counters, as these are an important safety warning feature. A thorough load train inspection is necessary to ensure product safety.

All Rice Lake RF linked scales/Dyna-Link 2 maintain two service counters for safety.

- The first counter (LFCnt) counts lifts above 25% of capacity
- The second counter (OLCnt) counts the number of times the RF linked scale has been overloaded

These counters warn the user to inspect the load train after a number of overloads or a long term frequency of high capacity lifts. Power up will be interrupted when the lift counter exceeds 16383 lifts or the overload counter exceeds 1023 overloads. Inspect the load train, then push any key to continue operation.

This feature is only available on MSI-8000HD Software release 2.00 and above. Service counters are available on the scale/Dyna-Link 2 front panel test function.

8.3.1 Access the Service Counters

Use the following steps to access the service counters

1. Program an **F-key** to **EE5E** ([Section 4.3 on page 16](#)).
2. Press **Fx-Test** and then immediately press **F1** again. The following items display:
 - **LFCnt** will display briefly, followed by the number of lifts
 - **OLCnt** displays briefly, followed by the number of times the weight has exceeded capacity
 - **E-CPAL** and its value is displayed
 - The unit returns to the weighing mode



NOTE: F1 must be pressed, if the Test function is set to F1, it will need to be pressed twice.

Reference the Crane Scale Safety and Periodic Maintenance Manual (PN 153105) for proper loading techniques to improve the safety and longevity of the crane scale or Dyna-Link. This publication is available at www.ricelake.com and is included on the CD shipped with the MSI-8000HD.

8.4 Mechanical Dimensions




Figure 8-1. MSI-8000HD Dimensions




Figure 8-2. MSI-8000HD Dimensions with Tilt Stand

8.5 Firmware Update

Updating firmware in the MSI-8000HD requires the following:

DCE serial cable (PN 150964, or build per DCE cable schematic)

PC with a terminal program (Teraterm Pro recommended)

USB to serial converter (if the PC does not have standard RS-232 serial ports)

Ensure the driver for the USB converter is properly installed, and that the terminal program is set up for the proper communications port.

The latest firmware code is available from the Rice Lake Weighing Systems technical support and can be emailed on request. The firmware version is displayed when the MSI-8000HD is turned on in form **01-04** (versions will vary). MSI-8000HD firmware updates do not require a recalibration of the connected scale. Consult the version release notes for information regarding the updated code.

1. Set up the terminal serial port to 8 data bits, no parity, 1 stop bit, 9600 BAUD, XON/XOFF (flow control).
2. Connect to the Dyna-Link serial port using the DCE cable. Connect the D9 connector to a PC or USB adapter.
3. Optional step: Test that there is a connection by typing {00FF01?}. If the connection is good the MSI-8000HD will respond with {000001r2;0;01E02;2011-07-08;11:05} or something similar.
4. On the terminal keyboard, type {ffff09=0199}.
5. Change the terminal serial port to 38400 Baud. Press the **↵** key to refresh the display. The following menu should appear.

MSI-8000HD RF Indicator SCALECORE3 BOOT LOADER Ver. xx-xx (c) Date, Time

(u) Download and program application code (bootloader version may vary)

(q) Query app code info

(g) Execute app code

(r) Refresh



NOTE: Your bootloader version may vary.

6. Type **u**

Terminal should display:

7. Send the .prg file using the file send feature of your terminal program. The character “#” will tick away as the ScaleCore programs.

Send File NOW, or press ^to abort: #####

#####

Completed

8. After file is received terminal should display “Completed.” Then the boot menu appears again.

MSI-8000 SCALECORE3 BOOT LOADER Ver. 00-05 (c) 2012-05-02 17:06

(u) Download and program application code (bootloader version may vary)

(q) Query app code info

(g) Execute app code

(r) Refresh

9. Optional step: send **q** to check the program. The ScaleCore will respond with a message that details the 32b checksum, the product ID and version, and the Application Code version number in the following form:

Computed Signature 76F481D8 32b CRC must match (76F481D8 is an example only)

Received Signature 76F481D8

Product ID 07 MSI-8000 product family

Product Version ID 00 Optional features code

App Code Version 01-04 Firmware version number

If the CRC Signature does not match, go back to [Step 4 on page 50](#) and try again.

10. Send an “r” to restore the boot menu.

MSI-8000 SCALECORE3 BOOT LOADER Ver. 00-05 (c) 2012-05-02 10:55

- (u) Download and program application code (bootloader version may vary)
- (q) Query app code info
- (g) Execute app code
- (r) Refresh

11. Send a “g.” The MSI-8000HD RF Indicator should start.

8.6 Factory Reset

Resetting the unit will change all settings back to the default factory settings.

1. Press the calibration switch and  simultaneously. *SurEP* displays.
2. Press  to reset the current indicator settings to the default factory settings. *FL* will display.
3. An initial calibration will need to be performed on the current load cell ([Section 5.2 on page 24](#)).



IMPORTANT: Pressing  will reset only the current load cell calibration settings ([Section 5.4 on page 28](#)).



NOTE: Press the  to cancel reset and return to the previous menu.

9.0 Specifications

Enclosure

IP66 milled anodized aluminum with O-ring gaskets

Keypad

On/Off, Zero (100%), Tare, Print, and two user-defined keys for the following functions: peak hold, high resolution, total, view total, net/gross, units switching

Display

6-digit 1.0" (26.4 mm) LCD

Units Displayed

Pounds, kilograms, tons, metric tons, kilonewtons

Annunciators

Stable, COZ, peak, kg, kN, lb, M, ton, setpoint, function LEDs

Channels: 1, 2, 3, 4, TTL

Power

Legal 90–264 VAC, 9–36 VDC

Industrial 90–267 VAC, 9–36 VDC, 18–72 VDC, 120–300 VDC

Operating Temperature

Legal 14°F–104°F (-10°C–40°C)

Industrial -4°F–140°F (-20°C–60°C)

AD Channels

Up to four AD sensors, monitored individually, in pairs, or sum

Service Counters

A/D version only

A/D Inputs

Two independent or summing load cell inputs

Excitation

4.8 V current limited and over-voltage protected

Filtering

Off, Low, Hi-1, Hi-2

RF Radio Link

2.4 GHz 802.15.4

RF Effective Range

Typically < 100' (33 m)

Data I/O

Dual RS-232 comm ports

Warranty

One-year limited

Approvals



NTEP

COC #15-110

Accuracy Class: III/IIIL $n_{\max}$: 10,000



© Rice Lake Weighing Systems Content subject to change without notice.

230 W. Coleman St. • Rice Lake, WI 54868 • USA USA: 800-472-6703 • International: +1-715-234-9171