

Rice Lake RS-130/RS-160

Main Body, Bench



RS-130




RS-160

Part Number/Price

Ref #	Part #	Description	Price
1	85715	Upper plastic cover	Consult
2	170020	Rear display overlay, RS-130	Consult
2	170021	Rear display overlay, RS-160	Consult
3	171653	Rear display, PCB, 30 lb, RS-130	Consult
3	171698	Rear display, PCB, 60 lb, RS-160	Consult
4	170013	Membrane keypad and overlay	Consult
5	170018	Operator display overlay, RS-130	Consult
5	170019	Operator display overlay, RS-160	Consult
6	165162	Main CPU board with LCD, RS-130 (includes M1–M9, unit price, tare, and unit of measure keys)	Consult
6	171697	Main CPU board with LCD, RS-160 (includes M1–M9, unit price, tare, and unit of measure keys)	Consult
7	171656	Spider, upper aluminum structure	Consult
8	50624	Load cell, 30 lb, RS-130	Consult
8	132268	Load cell, 60 lb, RS-160	Consult
9	171657	Spider, lower aluminum structure	Consult
10	85710	Rechargeable battery	Consult
11	85714	Base plastic plate	Consult
12	85718	Power switch	Consult
13	85716	Rubber foot	Consult
14	178072	Transformer	Consult
Additional Parts Available			
	175421	AC base seat	Consult
	15438	Power cord	Consult
	85711	Dust cover	Consult
	88574	Plastic platter	Consult
	88575	SST cover for the platter	Consult
	178058	Backlight kit	Consult
	178057	CPU, Eprom RS-160	Consult
	115263	Plastic sealing pin	Consult
	115927	Level bubble	Consult
	178059	17-pin LCD display, RS-130, RS-160	Consult

Rice Lake RS-130/RS-160

Main Body, Bench



Price Computing Scales