

Uni-9 Starter Keyboard

Uni-9

Copy the "Data02" folder to a USB flash drive. In the **File Save/Load** menu, load file "Uni-9 Starter Presets" to the scale. Edit the keyboard as needed.

SALES / PLU 0 NOV.19.2014 (WED) 01:43

CHECK THE WEIGHT BEFORE PRODUCTION.
ENTER PLU No. AND PRESS [PLU] KEY.

TARE	lb	ZERO	WEIGHT	lb	UNIT PRICE	\$/lb	TOTAL PRICE	\$
0.000			0.000		0.00		0.00	

CAT 1

CAT 2

CAT 3

CAT 4

CAT 5

CAT 6

PRINTING

MANUAL

🔍

DEPT.

🌐
BROWSER

Top Sellers

CHICKEN THIGHS

RIB EYE STEAK BONE-IN

FRESH SQUID

PEACHES

ROAST BEEF

7

8

9

4

5

6

1

2

3

C

0

PLU

←

FEED

TARE

ZERO

Category Page

SALES / PLU 309 NOV.19.2014 (WED) 01:43

CHICKEN LEGS

TARE	lb	ZERO	WEIGHT	lb	UNIT PRICE	\$/lb	TOTAL PRICE	\$
0.000			0.000		1.99		0.00	

Pack Date

NOV.19.2014

Sell By Date

NOV.19.2014

LOGO

40

FORMAT

0

CASE WEIGHT

WT.

INDGREDIENTS

25

COUNTRY

25

1 PINT

1/2 PINT

1/4 PINT

PRN MD

MANUAL

PRN QTY

ERROR LOG

🖨️
PRINT

STOP PRINT

7

8

9

4

5

6

1

2

3

C

0

PLU

FIX

←

FEED

TARE

ZERO

Capacity 0-15lb x 0.005lb 15-30lb x 0.01lb

Uni-9 Starter Keyboard

SALES / PLU 600 NOV.19.2014 (WED) 01:43

**10# CHICKEN
DRUMSTICKS**

PCS	@/	UNIT PRICE \$	TOTAL PRICE \$
1	1	7.90	7.90

Pack Date: _____ INDGREDIENTS: 0

Sell By Date: NOV.27.2014 COUNTRY: 0

LOGO: 0 %OFF: _____ \$ OFF U/P: _____

FORMAT: 0 PRN MD: MANUAL

CASE WEIGHT: _____ PRN QTY: _____

BAKERY WT.: _____ LABEL BATCH: _____ ERROR LOG: _____

1 PINT 1/2 PINT 1/4 PINT

PRINT

STOP PRINT

Capacity 0-15lb x 0.005lb 15-30lb x 0.01lb

Function Key Pages

Category Pages

SALES / PLU 0 NOV.19.2014 (WED) 01:44

**CHECK THE WEIGHT BEFORE PRODUCTION.
ENTER PLU No. AND PRESS [PLU] KEY.**

TARE	lb	ZERO	WEIGHT	lb	UNIT PRICE \$/lb	TOTAL PRICE \$
0.000			0.000		0.00	0.00

7 8 9

4 5 6

1 2 3

C 0 PLU

ZERO

← FEED TARE

Capacity 0-15lb x 0.005lb 15-30lb x 0.01lb

Uni-9 Starter Keyboard

SALES / PLU 0 NOV.19.2014 (WED) 01:44

CHECK THE WEIGHT BEFORE PRODUCTION.
ENTER PLU No. AND PRESS [PLU] KEY.

TARE	lb	ZERO	WEIGHT	lb	UNIT PRICE	\$/lb	TOTAL PRICE	\$
0.000			0.000		0.00		0.00	

7

8

9

4

5

6

1

2

3

C

0

PLU

←

FEED

TARE

Capacity 0-15lb x 0.005lb 15-30lb x 0.01lb

SALES / PLU 0 NOV.19.2014 (WED) 01:44

CHECK THE WEIGHT BEFORE PRODUCTION.
ENTER PLU No. AND PRESS [PLU] KEY.

TARE	lb	ZERO	WEIGHT	lb	UNIT PRICE	\$/lb	TOTAL PRICE	\$
0.000			0.000		0.00		0.00	

7

8

9

4

5

6

1

2

3

C

0

PLU

←

FEED

TARE

Capacity 0-15lb x 0.005lb 15-30lb x 0.01lb

Uni-9 Starter Keyboard

SALES / PLU 0 NOV.19.2014 (WED) 01:44

CHECK THE WEIGHT BEFORE PRODUCTION.
ENTER PLU No. AND PRESS [PLU] KEY.

TARE	lb	ZERO WEIGHT	lb	UNIT PRICE	\$/lb	TOTAL PRICE	\$
0.000		0.000		0.00		0.00	

7	8	9
4	5	6
1	2	3
C	0	PLU
		ZERO
←	FEED	TARE

Capacity 0-15lb x 0.005lb 15-30lb x 0.01lb

SALES / PLU 0 NOV.19.2014 (WED) 01:45

CHECK THE WEIGHT BEFORE PRODUCTION.
ENTER PLU No. AND PRESS [PLU] KEY.

TARE	lb	ZERO WEIGHT	lb	UNIT PRICE	\$/lb	TOTAL PRICE	\$
0.000		0.000		0.00		0.00	

7	8	9
4	5	6
1	2	3
C	0	PLU
		ZERO
←	FEED	TARE

Capacity 0-15lb x 0.005lb 15-30lb x 0.01lb

Uni-9 Starter Keyboard

SALES / PLU 0 NOV.19.2014 (WED) 01:45

CHECK THE WEIGHT BEFORE PRODUCTION.
ENTER PLU No. AND PRESS [PLU] KEY.

TARE	lb	ZERO WEIGHT	lb	UNIT PRICE	\$/lb	TOTAL PRICE	\$
0.000		0.000		0.00		0.00	

7	8	9
4	5	6
1	2	3
C	0	PLU
		ZERO
SUBCATEGOR Y	←	FEED TARE

Capacity 0-15lb x 0.005lb 15-30lb x 0.01lb

SALES / PLU 0 NOV.19.2014 (WED) 01:45

CHECK THE WEIGHT BEFORE PRODUCTION.
ENTER PLU No. AND PRESS [PLU] KEY.

TARE	lb	ZERO WEIGHT	lb	UNIT PRICE	\$/lb	TOTAL PRICE	\$
0.000		0.000		0.00		0.00	

7	8	9
4	5	6
1	2	3
C	0	PLU
		ZERO
BACK TO CAT	←	FEED TARE

Capacity 0-15lb x 0.005lb 15-30lb x 0.01lb

Uni-9 Starter Keyboard

SALES / PLU 0
NOV.19.2014 (WED) 01:45

CHECK THE WEIGHT BEFORE PRODUCTION.
ENTER PLU No. AND PRESS [PLU] KEY.

TARE	lb	ZERO	WEIGHT	lb	UNIT PRICE	\$/lb	TOTAL PRICE	\$
0.000			0.000		0.00		0.00	
							7	8
							4	5
							1	2
							C	0
								PLU
								ZERO
							←	FEED
								TARE

Capacity 0-15lb x 0.005lb 15-30lb x 0.01lb